









PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.


BERGEN 40




4x40  × 110




4x50  × 450

5x70  × 35


6x140  × 100

M8x70  × 12

LAY OUT THE FOUNDATION BEAMS
AND SQUARE IT BY MEASURING
FROM CORNER TO CORNER.



BERGEN 40






MAKE SURE THAT THE FOUNDATION
IS INSTALLED ON A LEVEL SURFACE.
CHECKING ALL DIRECTIONS,
INCLUDING CORNER TO CORNER. 1%

ATTACH FOUNDATION BEAMS
WITH SCREWS.

BERGEN 40



6x140
× 4
Ø 5 mm



ATTACH LOGS TO THE
FOUNDATION.





BERGEN 40




$5 \times 70 \times 6$ $6 \times 140 \times 10$
 $\phi 4 \text{ mm}$ $\phi 5 \text{ mm}$




THE WALL LOGS WILL HANG OVER
THE FOUNDATION BEAMS BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. 3%

ATTACH THE NEXT ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.


5×70  $\times 4$ 6×140  $\times 5$
 $\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 







AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BERGEN 40









DON'T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

BERGEN 40



ATTACH **HANDRAILS** INTO
WALL LOGS WITH SCREWS.




4×40
× 36
Ø 3 mm





HR1

HR2

BERGEN 40










ATTACH TOP LOGS INTO
WALL LOGS WITH SCREWS.

BERGEN 40



6x140
× 40

Ø 5 mm




CONNECT THE ROOF **PURLINS** (RFR)
WITH **RD** BEFORE INSTALLING THEM
ON TOP OF THE **CORNERS**.

BERGEN 40




INSTALL THE **ROOF** PURLINS AND
ATTACH THEM WITH SCREWS.

6x140
× 4
Ø 5 mm



BERGEN 40





INSTALL THE **ROOF** PURLINS (RFB) AND ATTACH THEM WITH SCREWS.

BERGEN 40

5×70 $\times 16$ 6×140 $\times 16$

$\Phi 4 \text{ mm}$

$\Phi 5 \text{ mm}$





PLACE THE FIRST **ROOFBOARD** FLUSH
WITH THE **END** OF THE PURLINS AND
ATTACH WITH SCREWS

4x50
× 424






BERGEN 40



RB21





INSTALL THE ROOF TOP AND ATTACH IT
WITH SCREWS. ATTACH FASCIA TRIMS
INTO ROOFPURLINS.

4x40
× 56




BERGEN 40

WINDBOARD CONNECTS BOTTOM LOG WITH THE TOP LOG. SAW THE WINDBOARD INTO THE RIGHT LENGTH. FOR THE TOP BOLT, DRILL 8MM HOLE THROUGH THE WINDBOARD.



BERGEN 40



WINDBOARD

DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLTS. 99%

WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BERGEN 40

